

Safety with DataSave



A solution by **tapio**





to prevent data loss of your machines^{1,2}.

 $^{^{\}rm 1}$ tapio partners with integrated their machines. $^{\rm 2}$ availability varies by machine type and manufacturer and needs to be check individually.

DataSave | Pricing

tapio

Price (without tax)

15,00 Euro

License Per 1 month per machine^{1,2}

Extension Automatically, to one month

User unlimited

Cancelation period Until 3 day before renewal

Add on package

0 DataSave | Requirements

> Internet Connection Download 385 kbit/s

Machines tapio connected machines^{1,2}

O DataSave | Function

The machine^{1,2} automatically creates backups of the production and configuration files (individually depending on the machine manufacturer) in tapio for all supported machines^{1,2}. Thus, you are protect against loss of data and enable faster service recovery in case of machine^{1,2} failures. The backup time can be defined individually on each machine^{1,2} with a DataSave license.

 $^{^{1}}$ tapio partners with integrated their machines. 2 availability varies by machine type and manufacturer and needs to be check individually.



- 1 Register your company at www.tapio.one
- Register your machines 1,2 in your company account. The connection of tapio ready machines 1,2 with tapio is automated (free of charge). 2 "tapio readiness" and possible updates can be checked with the machine manufacturer.
- Go to the tapio shop and buy DataSave licenses per machine^{1,2} 3
- Assign purchased DataSave licenses to your active machines^{1,2} 4
- On the machine^{1,2}, open the corresponding manufacturer's application and 5 define the backup time per machine^{1,2} Done.

All video tutorials you find here

DataSave | Support

Phone +49 7445 8379 949

E-mail serviceatapio.one

Reachable Monday to Friday from 8 am to 5 pm (MEZ)

Tutorials/ Videos



www.tapio.one/en/faq

Developed by tapio GmbH, Karl-Berner-Straße 4, 72285 Pfalzgrafenweiler

 $^{^{}m 1}$ tapio partners with integrated their machines. $^{
m 2}$ availability varies by machine type and manufacturer and needs to be check individually.