




# Efficient cutting processes with intelliDivide advanced

Alternatives



A HOMAG App



For quick, efficient optimizations results

<sup>1</sup> Produced parts are parts from cutting patterns which are printed or downloaded in any format by using the appropriate function



## intelliDivide advanced

### | Pricing

**Price**  
(excluding VAT)

**395,00 Euro**

**Licence**

For 1 month and a max. production of 100.000 parts

**Renewal**

automatically

**Users**

unlimited

**Notice period**

3 days ahead of renewal

**Additional packages**

-



## intelliDivide advanced

### | Requirements

**Mobile Devices**

Mid-class mobile device  
Android 5.0 or newer

wireless, WiFi

54 Mbit/s (IEEE 802.11g/n)

**Internet access recommendation**

wireless, Mobile

min. 3G (UMTS HSPA+/LTE)

16 Mbit/s (DSL 16.000)

Full functionality for tapio ready saws

For HOMAG machines:

- powerControl V2
- powerTouch V2.1
- Panel saws with CADmatic 5.1

Functional limitations may apply when used with other machines

Up-to-date web browser for web app, such as:

**Browser**

IE11, Firefox, Chrome, Safari, Edge

(Chrome recommended, other browsers may cause display errors)

intelliDivide is a cutting optimization program for optimizing two-dimensional, panel-shaped materials

intelliDivide accelerates the cutting of panel-shaped materials through more efficient processes that reduce time requirements and waste. The software is compatible with a wide range of machines — from basic circular saws to pressure beam saws.

intelliDivide optimizes your cutting processes. The software uses modern technologies, such as machine learning (AI) and the Internet of Things (IoT).

intelliDivide is a cloud-based "software as a service" application (SaaS). The complex optimization calculations are carried out in the cloud on several servers at the same time.

intelliDivide uses servers hosted by HOMAG as well as the global Microsoft Azure cloud solution.

As a browser-based application, intelliDivide is platform-independent, so you can control the intelligent cutting solution across a wide variety of devices: Windows PCs and laptops, tablets, and even smartphones. However, functionality is somewhat limited on smartphones.

The possibility of integrating a machine depends on the manufacturer, model, technical features and potentially required options. Please contact the respective manufacturer to find out whether your machine is tapio-ready.

If machines that are not tapio-ready need to be parametrized, integrated and controlled, this may require additional work.

With intelliDivide, you can create cutting patterns for an unlimited number of machines.

Using intelliDivide, you can download cutting pattern data directly to your machines (depending on the machine and the manufacturer) or print the cutting patterns for further use.

Multiple optimization algorithms make it possible to calculate a range of variants and create optimal cutting patterns simultaneously. The number of solutions displayed may vary depending on the cutting task.

intelliDivide recommends a "balanced solution." Solutions are presented as suggested variants.

For each optimization task, intelliDivide suggests additional, appropriate solutions with a different weighting.

The optimization algorithms suggest the ideal solution for your production order. This "balanced solution" is the best compromise between consumption of time and materials, and handling.

There may of course be occasions when you do not want to use the "balanced solution."

Simply select a different cutting variant and intelliDivide will automatically suggest more solutions.


### Data entry

- Manual input of part- and board data
- Transfer information from spreadsheets using „copy & paste“
- Selection of machine and parameter settings
- Immediate display of errors

Description	Material	Length (mm)	Width (mm)	Number	Number plus	Grain	Tello-ID	Kundenname	Kundenauftrag	Position
1 W-ROBE-TOP	MFC18-BEECH	9996	599	4		Lengthwise	0.6	BEECH-TAPE-22MM		BEECH
2 W-ROBE-END-LEFT	MFC18-BEECH	578	1782	4		Cross	1.0			
3 W-ROBE-END-RIGHT	MFC18-BEECH	578	1782	4		Cross	1.0			
4 W-ROBE-BASE	MFC18-BEECH	954	578	8		Lengthwise	0.6			
5 W-ROBE-PLINTH	MFC18-BEECH	954	125	4		Lengthwise	0.1			
6 W-ROBE-BACK	HARDBOARD-4MM	1000	1782	4		None	1.8			
7 W-ROBE-DOOR-L	MFC18-BEECH	499	1201	4		Cross	0.6			

### Comparison of alternative results


- Balanced result
- Optimized for handling
- Optimized for time
- Optimized for waste
- ...



<sup>1</sup> Produced parts are parts from cutting patterns which are printed or downloaded in any format by using the appropriate function

Detailed view of data corresponding to

- Production details
- Material
- Handling information
- Cutting patterns
- Stacking / sorting information



Other features

- Configurable text boxes for additional information (e.g. for labelling)
- Download of data in HOMAG-SAW format
- PDF Print
- Integrated Online-Help
- Tutorials

Information boxes

Add

Title	Type			
Part ID	Text, optional, Length: 30	↓	Delete	Edit
Customer name	Text, optional, Length: 30	↑ ↓	Delete	Edit
Customer order	Text, optional, Length: 30	↑ ↓	Delete	Edit
Position / article	Text, optional, Length: 30	↑ ↓	Delete	Edit
Production order / batch	Text, optional, Length: 30	↑ ↓	Delete	Edit
Date	Date, optional	↑ ↓	Delete	Edit
Longitudinal edge 1	Text, optional, Length: 30	↑ ↓	Delete	Edit
Longitudinal edge 2	Text, optional, Length: 30	↑ ↓	Delete	Edit
Cross edge 1	Text, optional, Length: 30	↑ ↓	Delete	Edit
Cross edge 2	Text, optional, Length: 30	↑ ↓	Delete	Edit
Edge diagram	Text, optional, Length: 15	↑ ↓	Delete	Edit
Front laminate	Text, optional, Length: 30	↑ ↓	Delete	Edit
Back laminate	Text, optional, Length: 30	↑ ↓	Delete	Edit
2. Cut size length	Floating-point number, optional, min. value: 0, max. value: 9999.9	↑ ↓	Delete	Edit
2. Cut size width	Floating-point number, optional, min. value: 0, max. value: 9999.9	↑ ↓	Delete	Edit
Finished length	Floating-point number, optional, min. value: 0, max. value: 9999.9	↑ ↓	Delete	Edit
Finished width	Floating-point number, optional, min. value: 0, max. value: 9999.9	↑ ↓	Delete	Edit
CNC program 1	Text, optional, Length: 30	↑	Delete	Edit

<sup>1</sup> Produced parts are parts from cutting patterns which are printed or downloaded in any format by using the appropriate function

API interface for data upload

Cut Rite results can be uploaded automatically, in order to generate additional alternatives. This gives immediate transparency to additional savings.

Common
API access
Info fields

**Authentication**

User ID

[redacted]
📄

Authentication key

[redacted]
📄

Console application

Example call-up

intelliDivide.exe -command optimize -subscriptionId 88bfa9dd-d567-4954-a8a6-67212782db8a -userId [redacted] -authkey 10[redacted]
📄

[Download console application](#)

<sup>1</sup> Produced parts are parts from cutting patterns which are printed or downloaded in any format by using the appropriate function

1	Register your enterprise on <a href="http://www.tapio.one">www.tapio.one</a> <a href="#">YouTube Tutorial</a>
2	Add your machines to your subscription. The connection of tapio ready machines with tapio is automated (free-of-charge service). „tapio readiness“ and possible updates can be checked with the machine supplier <a href="#">YouTube Tutorial</a>
3	Add your colleagues as users to your account <a href="#">YouTube Tutorial</a>
4	Open the tapio shop and subscribe to intelliDivide <a href="#">YouTube Tutorial</a>
5	Start intelliDivide at <a href="https://intellidivide.homag.cloud">https://intellidivide.homag.cloud</a>
6	Enter your data in intelliDivide <a href="#">YouTube Tutorial</a>
7	Download the desired result <a href="#">YouTube Tutorial</a>

**Phone**

+49 7443 13-6000

**Email**

softwaresupport@homag.com

**Availability**

Monday to Friday from 8 a.m. to 5 p.m.

**Tutorials/ Videos**



intelliDivide movie

Developed by HOMAG Plattenaufteiltechnik GmbH, Holzmastr. 3, D-75365 Calw